



DC Sports
13000 Temple Ave
City of Industry Ca, 91746
T. 626-937-6988
www.dcsports.com

SRI6515
SHORT RAM INTAKE INSTALLATION INSTRUCTIONS
2002-2006 ACURA RSX BASE MODEL

**!!! READ ALL INSTRUCTION THOROUGHLY BEFORE BEGINNING
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE
AND/OR SYSTEM DAMAGE!!!**

*****IF UNSURE ABOUT INTAKE SYSTEM INSTALLATION PLEASE HAVE A
REPUTABLE PERFORMANCE SHOP OR A LICENCED MECHANIC
INSTALL THIS SYSTEM*****

*****FOR YOUR SAFETY, ALLOW ENGINE TO COOL FOR AT LEAST AN
HOUR BEFORE BEGINNING INSTALLATION*****

*****PLEASE CHECK AND MAKE SURE ALL HARDWARE IS PRESENT
BEFORE INSTALLATION. PARTS LIST ON LAST PAGE*****

A.R.B INFORMATION

*****THIS DC SPORTS INTAKE ARE CARB EXEMPT
PER EO#D-370-13 FOR 2002-2006 RSX Base 2.0L ONLY*****

TOOLS REQUIRED

**Ratchet 8mm, 10mm, and 11mm deep socket
Flat Screwdriver
Pliers
6" Extension**

REMOVAL OF STOCK INTAKE AND INSTALLATION OF INTAKE SYSTEM

1. Unclip the wire harness attached to the OEM intake tube.
2. Loosen both clamps on each side of the OEM intake tube.
3. Locate and unplug the air temp sensor on the OEM intake tube.
4. Locate and unplug the vacuum hose on the OEM intake tube.
5. On the valve cover slide the clamp securing the secondary crankcase breather hose from the primary breather hose.
6. Locate and remove two 10mm bolts and one 10mm nut securing the air box to the engine.
7. Remove the factory air box from the vehicle.
8. Remove the factory intake tube from the vehicle.
9. Remove the factory vacuum hose from the engine and replace with provided 8mm vacuum hose.
10. On the throttle body install provided 2.75"/3.00" reducer coupler with two hose clamps but only tighten down the clamp on the throttle body side as of now

11. Loosely install the DC Sports intake tube onto the throttle body.
12. Notice the welded bracket on the DC Sports intake tube and install the provided vibration mount between the welded bracket and the engine where the bracket makes contact.
13. Install provided nut and washer to lock down the welded bracket onto the vibration mount.
14. Tighten remaining clamp on the throttle body securing intake tube.
15. Plug the air temperature sensor into the rubber grommet on the intake tube.
16. Install provided 15.9mm crankcase breather hose onto the intake nipple and attach the other end of the hose into the factory hose off the valve cover.
17. Install the 8mm vacuum hose onto the intake tube.
18. Install the filter onto the DC Sports intake tube.
19. Installation is now complete check all work performed.

*****LIMITED 3 YEAR WARRANTY*****

DC Sports only warranty's intake systems due to poor workmanship. We do not cover normal wear and tear damages due to misuse or abuse. We do not warranty the finish of intake tubes.

Warranty covers the original owner of intake system by having proof of purchase. We have the right to void all warranty if you cannot provide the information needed by DC Sports. DC Sports does not cover any cost for installation or removal of products.

*****CAUTION*****

DC Sports does not assume any liability for damage caused by rain or floods causing the intake system for taking on water. We recommend that you remove the cold air intake system due to wet conditions.

*****WARRANTY CLAIMS*****

All warranty claims must be shipped prepaid by the customer to DC Sports. Warranty claims must have an RMA (Return Merchandise Authorization) number on the box or package will be refused and sent back to the shipper.

PARTS LIST

Quantity	Part Number	Part Description
1	DCSRP6515	SRI6515 INTAKE TUBE
1	DCCP275-300	2.75/3.00" COUPLER REDUCER
7"	DCVH8MM	8MM VACUUM HOSE
3.75"	DCVH159MM	15.9MM VACUUM HOSE
1	DCCL275	2.75" CLAMP
1	DCCL300	3.00" CLAMP
1	DCVM6MM	M6 M/M VIBRA MOUNT
1	DCRG58	5/8" RUBBER GROMMET
1	DC-RAF300	3.00" DC Sports FILTER PACK
1	TMTAG-CARBE013	D-370-13 carb sticker
2	DCDECAL	DC Sports DECALS

THANK YOU FOR CHOOSING DC SPORTS